




DAYTONA DOS 2021

User Manual

TIPS & TRICKS

WATCH OUT FOR USEFUL TIPS & TRICKS REGARDING OUR PRODUCTS UNDER
WWW.DUOTONESPORTS.COM.



CONTENT

1.	RELEASE OF LIABILITY	4
2.	SAFETY AND PRECAUTIONS	6
2.1.	Hydrofoil Safety	6
2.2.	Dangers from the Hydrofoil	7
2.3.	Dangers from the Board or Hydrofoil	7
2.4.	Dangers to uninvolved third parties	8
2.5.	Weather related Dangers	8
3.	ASSEMBLING/DISMANTLING THE HYDROFOIL	10
3.1.	Overview of the Daytona DOS	10
3.2.	Assembling	11
3.3.	Dismantling	11
4.	CARE OF THE HYDROFOIL	12
5.	WARRANTY POLICY	13

1. RELEASE OF LIABILITY

RELEASE OF LIABILITY, CLAIM WAIVER, ASSUMPTION OF RISK

By assembling and/or using this DUOTONE product, you agree that you have read and understood the entire DUOTONE product owner's manual, including all instructions and warnings contained in that manual, prior to using the DUOTONE product in any way. You additionally agree that you will ensure any additional or subsequent user of your DUOTONE product will read and understand the entire DUOTONE product Owner's Manual, including all instructions and warnings contained in that manual, prior to allowing that person to use your DUOTONE product.

ASSUMPTION OF RISK

Use of the DUOTONE product and any of its components involve certain inherent risks, dangers, and hazards that can result in serious personal injury and death to both the user and to nonuser third parties. In using the DUOTONE product, you freely agree to assume and accept any and all known and unknown risks of injury to you and to third parties while using this equipment. The risks inherent in this sport can be greatly reduced by abiding by the warning guidelines listed in this owner manual and by using common sense.

RELEASE AND WAIVER OF CLAIMS

IN CONSIDERATION OF THE SALE OF THE DUOTONE PRODUCT TO YOU, YOU HEREBY AGREE TO THE FULLEST EXTENT PERMITTED BY LAW, AS FOLLOWS:

To waive any and all claims, that you have or may in the future have against Boards & More GmbH and all related parties resulting from use of the DUOTONE Product and any of its components.

To release Boards & More GmbH and all related parties from any and all liability for any loss, damage, injury or expense that you or any users of your DUOTONE product may suffer, or that your next of kin may suffer, as a result of the use of the DUOTONE product, due to any cause whatsoever, including negligence or breach of contract on the part of Boards & More GmbH and all related parties in the design or manufacture of the DUOTONE product and any of its components. In the event of your death or incapacity, all provisions contained herein shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns, and representatives. Boards & More GmbH-related parties have not made and expressly deny any oral or written representations other than what is set forth herein and the DUOTONE product User's Manual.

2. SAFETY AND PRECAUTIONS

DUOTONE STRONGLY RECOMMENDS::

If you are not yet able to hydrofoil or if you feel insecure, you must attend a licensed school to learn the basics of this fantastic sport. Get familiar with the safety precautions, which are indispensable for safe hydrofoiling .

Hydrofoiling creates a heavy strain on your body. You should only go hydrofoiling if you are in good physical condition and suffer from no medical conditions that may prevent you from hydrofoiling. Always act carefully to not endanger yourself or anyone else. Do not endanger the safety of uninvolved third parties! Be aware of the risks you take and limit them to a minimum level!

Before going on the water make sure you are familiar with your DUOTONE equipment. For your own safety, read the following instructions as well as product descriptions very carefully.

2.1. HYDROFOIL SAFETY

- Only use on unobstructed stretches of water.
- Only ride the hydrofoil if you are a good swimmer and you are wearing a life jacket.
- Avoid power lines, telephone lines, airports, roads, buildings and trees.
- If you are using a board with a board leash, you must wear a helmet! Be aware of the general risks associated with water sports, such as stones and rocks, waves, sunburn, hypothermia, jellyfish, etc.

2.2. DANGERS FROM THE HYDROFOIL

WHEN HYDROFOILING YOU MIGHT FACE THE EXTREME FORCES OF THE ELEMENTS.

In rare cases the Hydrofoil can cause dangerous situations:

- You can hurt yourself through uncontrolled water take-offs caused by gusty conditions, and the danger of collision with obstacles.
- Risk of injury due to an inability to control the Hydrofoil in gusty conditions or waves.
- Risk of injury through uncontrolled falls caused by gusts, waves or flotsam.
- If the hydrofoil is used incorrectly, there is a risk of injury to the user and bystanders.
- Once the hydrofoil has been assembled, it must be kept under the covers when not in use to avoid possible injury to other people.

2.3. DANGERS FROM THE HYDROFOIL

The use of a hydrofoil board is a high-risk activity and can be extremely dangerous if implemented incorrectly. This can result in serious injury or even death for the user or other individuals in the vicinity. All users of the DUOTONE Hydrofoil must be aware of the associated risks. These include loss of control, collision with the board, collision with the Hydrofoil and even drowning. Some of the foil components are extremely sharp and thus pose a potential risk. To protect the rider and others against injury, the foil must be handled with special care from the point at which it is constructed until it is used. We recommend using a certified helmet at all times and an appropriate collision-proof or protective vest as well as a wetsuit and neoprene shoes. Do not exceed your capabilities and maintain control over the Hydrofoil at all times. Do not push beyond your limits when using the Foil Board with the Hydrofoil, and ride at a speed that is commensurate with your ability level. Be aware of your surroundings, and familiarise yourself with them. Do not endanger others by coming too close to swimmers, boats, jetties and other objects that could be damaged by you or the foil. Do not use the foil in shallow waters. This could also result in injury to you and damage to your foil. You should also be aware that individual components on this product are exposed to natural forces and may be subject to wear.

2.4. DANGERS TO UNINVOLVED THIRD PARTIES

- It is your responsibility to ensure that bystanders and other sportspeople are not put at risk or injured due to your actions or equipment.
- Do not use foils in any location where bystanders could be injured.

2.5. WEATHER RELATED DANGERS

- Avoid offshore wind.
- Be careful with onshore wind.
- Get information on tidal and sea current conditions at your spot!
- Get information from both the weather report and the locals on prevailing weather conditions.
- Never use the Hydrofoil with wind forces so strong that you are unable to maintain precise control.
- Do not use the Hydrofoil when wind conditions are likely to change dramatically.
- Never use this Hydrofoil when thunderstorms are nearby or when such storms have a good chance of developing (check the weather report!).
- Leave the water immediately when a storm is approaching. You are in a life threatening situation since you may be struck by lightning!


BFT	M/S	KM/H	MPH	KNOTS	DESIGNATION
0	0 - 0,2	0 - 0,8	0 - 0,6	0 - 0,5	Calm
1	0,3 - 1,5	0,9 - 5,5	0,7 - 3,5	0,6 - 3,0	Light Air
2	1,6 - 3,3	5,6 - 12,1	3,6 - 7,5	3,1 - 6,5	Light Breeze
3	3,4 - 5,4	12,2 - 19,6	7,6 - 12,2	6,6 - 10,5	Gentle Breeze
4	5,5 - 7,9	19,7 - 28,5	12,3 - 17,8	10,6 - 15,5	Moderate Breeze
5	8,0 - 10,7	28,6 - 38,8	17,9 - 24,0	15,6 - 20,9	Fresh Breeze
6	10,8 - 13,8	38,9 - 49,8	24,1 - 31,0	21,0 - 26,9	Strong Breeze
7	13,9 - 17,1	49,9 - 61,7	31,1 - 38,3	27,0 - 33,3	Near Gale
8	17,2 - 20,7	61,8 - 74,6	38,4 - 46,4	33,4 - 40,3	Gale
9	20,8 - 24,4	74,7 - 88,0	46,5 - 54,7	40,4 - 47,5	Strong Gale
10	24,5 - 28,4	88,1 - 102,0	54,8 - 63,6	47,6 - 55,3	Storm
11	28,5 - 32,6	102,1 - 117,0	63,7 - 73,0	55,4 - 63,4	Violent Storm
12	32,7 +	117,1 +	73,1 +	63,5 +	Hurricane

THE LISTED RISKS CANNOT BE COMPLETE.

The basic rules for Hydrofiling comply with those of common sense and are valid for all outdoor sports.

3. ASSEMBLING & DISMANTLING THE HYDROFOIL


3.1. OVERVIEW OF THE DAYTONA DOS



- 1 Mast
- 2 Front Wing
- 3 Back Wing
- 4 Fuselage

3.2. ASSEMBLING THE HYDROFOIL

1. Use the screws provided to screw the glider to the mast.
2. Make sure no sand or other dirt is in the inserts.
3. Hold the glider with the fuselage against the connection area on the mast and slide the three M6x40mm screws through the fuselage. Finally, screw these into the mast.
4. Insert the fourth M6x25mm screw through the fuselage, and screw this firmly into the mast.
5. Insert the upper end of the mast into the tuttle box on the hydrofoil board.
6. We recommend using two screws to attach your foil to the board in the following manner.
 - a. Use at least the inserts 1 & 5 to attach the foil to your board. Make sure the screws have been rotated at least 6 times when screwing them tightly into the insert. Check that the screws are not too long to avoid damage to the mast.
 - b. Use one of the inserts 2-4 to fit the front screw for the rear foot loop to your foil. Make sure the screw is long enough to go through both the tab on the foot strap and the board, so it can be screwed into the hydrofoil.
7. Remove the covers from the glider and mast before using the hydrofoil on the water.



3.3. DISMANTLING THE HYDROFOIL

To dismantle the Daytona DOS hydrofoil, follow the instructions above in reverse order.

6. HYROFOIL CARE

- Prevent any contact between the Hydrofoil and sharp stones, pieces of wood and other objects that could damage the surface or edges of the Hydrofoil.
- At the beach, expose the foil as little as possible to intense sunlight.
- Wash your foil in fresh water after use, particularly following exposure to sea water, to reduce the risk of corrosion.
- Make sure the foil is completely dry before you pack it away in the covers.
- Make sure no sand or other dirt collects in the inserts and that these are always clean when the Hydrofoil is being assembled.

9. WARRANTY POLICY

- DUOTONE Warrants this product to be free of major defects in material or workmanship to the original purchaser for a period of six months from the original date of purchase. This warranty is subject to the following limitations: The warranty is valid only when the product is used for foil wing foiling on water and does not cover products used in rental or teaching operations.
- DUOTONE will make the final warranty determination, which may require inspection and/or photos of the equipment, which clearly show the defect(s). If necessary, this information must be sent to the DUOTONE distributor in your country, postage prepaid.
- If a product is deemed to be defective by DUOTONE, the warranty covers the repair or replacement of the defective product only.
- DUOTONE will not be responsible for any costs, losses or damages incurred as a result of loss of use of this product. The warranty does not cover damage caused by misuse, abuse, neglect or normal wear and tear including but not limited to, rigging with other than DUOTONE components, damage due to excessive sun exposure, damage caused by improper handling or storage, damage caused by use in the waves or shore break and damage caused by anything other than defects in material and workmanship.
- This warranty is voided if any unauthorized repair, change or modification has been made to any part of the equipment.
The warranty for any repaired or replaced equipment is good from the date of the original purchase only.
The original purchase receipt must accompany all warranty claims.
The name of the retailer and date of purchase must be clear and legible.
There are no warranties that extend beyond the warranty specified herein.

WARRANTY CLAIMS

- Warranty claims must be processed and be issued a return authorization prior to shipping to DUOTONE.

